


LI'L POPPER

Li'L Popper control circuit breaker saves the technician dozens of blown fuses while he diagnoses control circuit failures. Simply plug the leads in to the ATC fuse receptacle on the board, and manually reset the Li'L Popper each time the breaker blows. Has a quick setting thermal cut out. Self adhering backing allows the contractor to leave the unit on the job site overnight if he is out of fuses. Free counter display by request. Alligator clip versions are available.

Control Board Circuit Breaker

Part #	Description
12-POP3	3 Amp control board circuit breaker
12-POP5	5 Amp control board circuit breaker



Z-Tool Nut Driver

Part #	Description
12-ZT10	180° Pivoting 1/4" and 5/16" Nut Driver

