

## LOCKING FLARE CAP

Prevents Unauthorized
Access to Refrigerant Lines
Model VCC-4



Contains 2 sets with locking hex wrenches

## COP-CAP™

## LOCKING FLARE CAP

- Stops tampering with system
- Prevents refrigerant theft
- Prevents access to refrigerant for mis-use

## **INSTRUCTIONS:**

- 1. Screw cap assembly onto fitting
- Turn down set screw with wrench, locking collar to hex shoulder of fitting or to base of the fitting threads, so that cap cannot be unscrewed.

